

TAKSTAR® 得胜



DL-8 电源时序器 Power Sequencer

使用手册 | User Manual

DL-8 电源时序器

■ 前言

感谢您选购得胜DL-8电源时序器,为了您能够更好地了解使用本产品,建议您在使用前仔细阅读本说明书。

若存在有疑问或者您有宝贵的建议,可通过拨打得胜官方服务热线400 6828 333或微信扫描二维码关注得胜官方公众号与我们联系。



■ 产品特性

- 通过前面板开关自动时序上电或关电;
- 8路可控通道+2路直通通道;
- 8路可控通道每路最大通过电流30A;总功率最大3500W;
- 每路带LED显示灯,实时反馈每个通道的工作状态;
- 实时电压显示,直观掌握设备所处地点的工作电压情况;
- 面板提供5V1A直流USB输出接口,可接照明灯使用;
- 采用高品质的万用座,对接紧密,不易脱落,适应各种规格的电源插头。

■ 适用范围

适用于会议室及多功能厅、KTV酒吧、工程安装与户外演出等专业场合

■ 产品配置

电源时序器.....	1台
说明书.....	1份

DL-8 电源时序器


■ 技术参数

- 通道数量:8路
- 辅助通道数量:2路
- 通道额定电流:13A
- 通道最大电流:30A
- 通道总功率:3500W
- 时序开关时间间隔:1 sec
- 电源:220V/50Hz
- 重量:约3kg
- 尺寸 (W*D*H):483mm*66.5mm*185mm

注: 以上数据由得胜实验室测试得到, 并拥有最终解释权!

■ 功能示意


前面板



- ① 直通电源输出接口
- ② 输出USB接口:输出5V/1A直流电源为USB供电照明灯供电。
- ③ 电源输出指示灯:亮起表示该通道电源输出接口已接通电源。
- ④ 直通开关按键:按下或弹起可以直通或者断开时序器背板电源接口电源。
- ⑤ 显示屏:显示当前市电的实时电压。
- ⑥ 电源开关:开启或关闭时序器。

DL-8 电源时序器

背面板



- ① 电源输入线
- ② 外置开关接线口: 从该接口接入外置开关可以控制时序器顺序开启或顺序关闭。
- ③ 电源输出插座

■ 安全警示

为避免电击、高温、着火、辐射、爆炸、机械危险以及使用不当等可能造成的人身伤害或财产损失, 使用本产品前, 请仔细阅读并遵守以下事项:

1. 使用产品时请确认所连设备与本产品是否匹配以及合理调整音量大小, 不要在超过产品功率及大音量下长时间使用, 以免造成产品异常;
2. 使用中若发现有异常(如冒烟、异味等), 请立即关闭电源开关并拔掉电源插头, 然后将产品送售后服务网点检修;
3. 本产品及附件都应放置在室内干燥通风处, 请勿长期存放在潮湿、灰尘多的环境, 使用中避免靠近火源、雨淋、进水、过度碰撞、抛掷、振动本机及覆盖通风孔, 以免损坏其功能;
4. 若产品需要固定于墙壁或天花板时, 请确保固定到位, 防止因固定强度不足导致产品发生跌落危险;
5. 使用该产品时需遵守相关安全规定, 法律法规明确禁止使用场合请勿使用本产品, 以免导致意外事故;
6. 请不要自行拆机改装或维修, 以防止出现人身伤害, 如有问题或服务需求请联系当地售后服务网点跟进处理。

DL-8 电源时序器

■ 关于图标含义解释



此符号表示，根据WEEE指令(2012/19/EU)和国家法律，由于这种类型的废弃物会有潜在的有害物质，可能对环境 and 人类健康产生负面影响，所以本产品不应与您的家庭垃圾一起处置，



应将本产品应交由授权的电气和电子设备（WEEE）回收站回收。同时，您在正确处理本产品的同时将有助于自然资源的有效利用。如需了解更多有关您可以在何处放置废物回收设备的信息，请联系您当地的城市办事处、废物管理局或家庭废物处理服务部门。

■ 关于本说明书

本说明书中内容符合截止印刷之日的技术规格。由于得胜公司会不断改进产品，本说明书可能不符合您的特定产品的技术规格。要获取最新版说明书，请访问得胜官网，然后下载说明书文件。技术规格、设备或另售的附件在各个地区可能有所不同，如有问题请与当地得胜销售网点确认。如需更多支持和深层产品信息，请浏览得胜官方网站：<https://www.takstar.com>

版权所有 ©2025 得胜。得胜、TAKSTAR及其各自标志是广东得胜电子有限公司在中国和/或其他国家/地区的注册商标或商标。所有其它商标均是其各自所有者的财产。

DL-8 Power Sequencer

■ Preface

Dear Customer,

Thanks for purchasing our product. Read this manual thoroughly for proper use.

If you have any questions or suggestions, please contact our local sales service.

■ Features

- Automatic power sequencing on/off via front panel switch.
- 8 controllable channels + 2 bypass channels.
- Each controllable channel supports a maximum current of 30A; total power capacity is 3500W.
- Each channel features an LED indicator for real-time status feedback.
- Real-time voltage display for monitoring the operating voltage at the device's location.
- Front panel includes a 5V 1A DC USB output for powering lights.
- High-quality universal sockets, compatible with various power plug standards.

■ Applications

For conference rooms, multipurpose halls, KTV bars, engineering installations, and outdoor performances.

■ Package Contents

1 × Power Sequencer

1 × User Manual

DL-8 Power Sequencer


■ Specifications

- Number of Channels: 8
- Number of Auxiliary Channels: 2
- Rated Current per Channel: 13A
- Maximum Current per Channel: 30A
- Total Power Capacity: 3500W
- Sequential Switch Time Interval: 1 sec
- Power Supply: 220V/50Hz
- Weight: Approx. 3kg
- Dimensions (W*D*H): 483mm*66.5mm*185mm

Note: The above data are measured by Takstar laboratory which has the final interpretation right!

■ Function Descriptions


Front Panel Functions



- ① Bypass Power Output Interface
- ② USB Output Interface: Provides 5V/1A DC power for USB-powered lighting devices.
- ③ Power Output Indicator: Lights up to indicate that the channel's power output is active.
- ④ Bypass Switch Button: Press to enable or disable power to the sequencer's rear panel power interface.
- ⑤ Display Screen: Shows the real-time voltage of the mains power.
- ⑥ Power Switch: Turns the sequencer on or off.

DL-8 Power Sequencer

Rear Panel Functions



- ① Power Input Cable
- ② External Switch Connection Port: Connect an external switch to control the sequential on/off operation of the sequencer.
- ③ Power Output Socket

DL-8 Power Sequencer

■ Safety Instructions

To avoid electric shock, overheat, fire, radiation, explosion, mechanical risk and injury or property loss due to improper use, please read and observe the following items before use:

1. Please check if the power of the connected equipment matches with that of this product before operation. Adjust the volume to proper level during operation. Do not operate at over-power or high-volume level for extended time to avoid product malfunction.
2. If there is any abnormality during use (e.g., smoke, strange odor), please kill the power switch and unplug from power source, then send the product to the local after-sales service for repair.
3. Keep this product and its accessories in a dry and ventilated area. Do not store in a humid or dusty area for extended time. Keep away from fire, rain, liquid intrusion, bumping, throwing, vibrating, or from blocking any ventilation openings, to prevent malfunction.
4. The product must, when installed on walls or ceilings, be fixed firmly in place at adequate strength to prevent from falling.
5. Please abide by safety rules during operation. Do not use the product in places prohibited by laws or regulations to avoid accident.
6. Do not disassemble or repair the product by yourself to avoid injury. If you have any questions or require any services, please contact our local after-sales service.

DL-8 Power Sequencer

■ Label Meanings



This symbol indicates that this product should not be disposed of with your household waste, according to the WEEE directive (2012/19/EU) and your national law. This product should be handed over to an authorized collection site for recycling waste electrical and electronic equipment (WEEE). Improper handling of this type of waste could have a possible negative impact on the environment and human health due to potentially hazardous substances that are generally associated with WEEE. At the same time, your cooperation in the correct disposal of this product will contribute to the effective usage of natural resources. For more information about where you can drop off your waste equipment for recycling, please contact your local city office, waste authority, or your household waste disposal service.

■ About This Manual

This manual contains up-to-date technical specifications as of printing. However, specifications contained herein may not conform to your particular product since Takstar is constantly improving its products. Also, specifications, devices or accessories available may vary from region to region. If you have any questions, please contact our local sales outlet. For the latest version/more information, please visit our website: <https://www.takstar.com/>

Copyright ©2025 TAKSTAR. TAKSTAR, 得胜 and their respective logos are registered trademarks or trademarks of Guangdong Takstar Electronic Co., Ltd. in the PRC, and/or other countries. All other trademarks are the property of their respective owners.

注意事项:

- 1. 本单为保修凭证，请用户妥善保管，如有遗失，恕不保修或退换。
- 2. 保修期限制：购买之日起十二个月内。
- 3. 除了不可抗力事件损坏外，由本公司负责，免费维修。
- 4. 如属保管不善或使用不当造成的损坏，维修点将酌情收费。
- 5. 擅自拆卸维修者，不予保修。
- 6. 以上保修条款仅限于中国市场适用（不含港澳台地区）。

产品服务保证书

姓名: _____ 电话: _____ 地址: _____
商品: _____ 型号: _____ 购买日期: _____ 年 ____ 月 ____ 日

维修记录栏（由维修员填写）	维修员签名	日期

◆广东得胜电子有限公司 ◆电话: 400-6828-333 ◆地址: 广东省惠州市博罗县龙溪街道富康一路2号



扫一扫，了解更多产品
Scan for more
product information

广东省电声工程技术研究中心 广东得胜电子有限公司制造

地址：广东省惠州市博罗县龙溪街道富康一路2号

服务热线：400 6828 333 传真：0752 6383950

邮箱：xs@takstar.com

网址：www.takstar.com

Guangdong Takstar Electronic Co., Ltd.

Address: No. 2 Fu Kang Yi Rd., Longxi Boluo

Huizhou, Guangdong 516121 China

Tel: 86 752 6383644 Fax: 86 752 6383952

Email: sales@takstar.com

Website: www.takstar.com